

**SHADYS Install Instructions**  
**Factory Standard Canopies**  
**Tomberlin Emerge Golf Cars**

**Step 1**

Clean inside of canopy with alcohol wipe, allow to dry. Apply primer to area where Velcro strip will be adhered to along inside of canopy and allow to dry for 10 minutes



**Step 2**

Attach Velcro strip along inside edge of canopy as shown.

**\*Tip: measure and cut one piece of adhesive Velcro the correct length of back of canopy and attach to inside back of canopy first. Cut remaining piece of Velcro in half and attach to each side beginning at back corner of canopy and working forward.**



**Step 3**

Attach Shadys to Velcro along inside edge beginning with back center.



**Step 4**

Lift seat, attach Velcro pad to smooth area along inside panel. Attach strap to Velcro pad and lower seat.



